WARNING: FOLLOW INSTRUCTIONS OR YOU WILL HAVE TO REPLACE YOUR JERSEY AND/OR PRACTICE JERSEY

Where to Place the PDI Badge

1. PDI Badge goes on the LEFT SHOULDER
   - **ONLY IF** you have a PDI Badge on your left shoulder already, then place your new PDI Badge on your RIGHT SHOULDER.
2. When you place the PDI Badge you should see if from the side profile, not from the front. See the image to the right for an example.
3. The bottom of the badge should be 3 inches from the bottom of the sleeve. **smaller youth size jerseys may have to be centered or 2 inches from the bottom of the sleeve.*
4. Center the badge horizontally on the sleeve
5. Print/Read and follow the iron on instructions. Make sure you DON'T BURN your jersey in the process with the iron.

Home Iron-on Instructions

1. Temperature - Turn Iron on highest setting without steam and let it heat up
2. Pre-Press Garment - Press garnet for 3-5 seconds to remove moisture and wrinkles
3. Peel - Peel off backing paper and position transfer sticky side down
4. Time/Pressure - Press firmly for 30 seconds while moving the iron in a slow circular pattern over the entire transfer
5. Finish - Remove Iron and peel transfer while it is still HOT.
6. Note - Post-press with Teflon Sheet or parchment paper for 5 sec to seal edges, if needed. (Recommended)

Commercial Applications Instructions

1. Press garnet for 3-5 seconds to remove moisture and wrinkles
2. Peel off backing paper and position transfer sticky side down
3. Press firmly for 8 seconds at 310°F (155°C) at medium pressure – PEEL HOT
4. Post-press with Teflon Sheet or parchment paper for 5 sec to seal edges